



S-Mod Brace:

- This part can be installed with the pipe in place, however it will be tight so removing the pipe is recommended.
 1. Remove two nuts holding on lower steering bushing.
 2. Place ZRP Brace, reinstall and hand tighten the two steering nuts.
 3. Install included 6mm bolts, hand tight.
 4. Torque steering nuts to 27ft-lbs, 6mm bolts to 6 ft-lbs.
 5. Find snow, pin it!

Remember: Performance Matters!



Please email zrp.engineering@gmail.com if there is any issue with your order. We will work tirelessly to make it right!

Like us on [fb.me/ZollingerRacingProducts](https://www.facebook.com/ZollingerRacingProducts) & Order at: ZOLLINGERRACINGPRODUCTS.COM

Remember: Performance Matters!