





Thule Rapid System Kit 1381

> Instructions

HONDA FR-V, 5-dr MPV, 04-09

HONDA Edix, 5-dr MPV, 04-09 (JPN)




ISO 11154-E

141381

C.20160712
519-1381-02



Bring your life

thule.com



1

	X (scale)	X (mm)	X (inch)
HONDA FR-V , 5-dr MPV, 04-09	62,5	1276	50 1/4
HONDA Edix , 5-dr MPV, 04-09 (JPN)	62,5	1276	50 1/4






	Y (scale)	Y (mm)	Y (inch)
HONDA FR-V , 5-dr MPV, 04-09	55,5	1206	47 1/2
HONDA Edix , 5-dr MPV, 04-09 (JPN)	55,5	1206	47 1/2

2

HONDA FR-V, 5-dr MPV, 04-09

HONDA Edix, 5-dr MPV, 04-09 (JPN)



3

	W (mm)	Z (mm)	W (inch)	Z (inch)
HONDA FR-V , 5-dr MPV, 04-09	360	720	14 1/8	28 3/8
HONDA Edix , 5-dr MPV, 04-09 (JPN)	360	720	14 1/8	28 3/8

